

How to copy remote buttons

To learn how to control your home TV by our V8 series remote controller, please follow the steps as below:

1. Prepare the TV remote controller which needs to be copied, and make sure it is full of battery.
2. Continuously press the White Key on V8 series remote controller for 5 seconds until the flashing red light turn into normal situation.



Press it for 5s until red light be normal, it turns into Copy Mode

For example: Learn how to swift TV IN mode (There are four keys on V8 series remote controller in Control TV area and all of them can do copy.)

Pressing TV IN Key on V8 series remote controller until the White key light starts to flash. At the same time, please quickly and continuously press TV INPUT key on TV remote controller until the White button flashing light on V8 remote controller turns into normal light. When all done, copying TV IN succeed.

The method of copying other function keys is the same. When finished, please Press OK key to exit.



Note: During copying period, please keep the two remote controllers Infrared interfaces close to each other. If it fails to copy, you can try once again. However, we can't make sure all remotes can copy successfully.